

FIXING PREMIUM PANELS TO FENCE POSTS

1. Use a 6.5mm (1/4 inch) drill bit to drill through both layers of the 50mm square premium frame. Drill an adequate number of holes at adequate spacings to suit the panel height on both sides.
2. Use a 12-13mm (1/2 inch) drill bit to drill through the receiver channel layer only of the premium frame at all points where you have drilled your previously drilled 6.5mm holes.
3. Use your drilled side channels to position and mark your posts.
4. Now use an appropriate size self drilling screw to secure your side channels to the posts.
5. You are now ready to insert and position the slat infill.

